

Assembly Instructions

- Knock-Down Bun Pan Racks

1. Choose a level area for assembly.
2. Lay out parts: (4) $\frac{3}{4}$ " x 1" – I-Beam Spacers
(2) 1" x 1½" – Angle Spacers
(8) Pieces of 1" Channel, 1" Long
(2) Pre-Assembled Rack Sides
(8) $\frac{3}{8}$ " x 2" – Hex Bolts
(4) $\frac{1}{4}$ " x $\frac{1}{2}$ " – Carriage Bolts & Nuts
3. Attach all bar and angle spacers to one pre-assembled rack side as shown (**Do Not Tighten Bolts**).
4. Attach remaining pre-assembled rack side and tighten all bolts.
5. Install casters last.

Assembly Video

